


Interim Manual Blackbody Radiation Sliderule*



*This is a temporary manual and will be replaced shortly with a two color typeset manual.

Automatic test sets

radiant standards
blackbody sources
lamp sources
low level electronics
tuned amplifiers
digital instruments
temperature standards
radiometers
industrial controls

BLACKBODY RADIATION SLIDERULE

Explanation of Scales

Planck's expression for spectral radiant flux density into a surrounding hemisphere in the wavelength interval λ to λ + d λ is

$$H \lambda = \frac{2 \pi hc^2}{\lambda^5} \frac{1}{e^{\frac{hc}{\lambda}k} T_{-1}} \left[W/cm^2 - \mu m \right]$$

The corresponding expression for spectral radiant photon density

Q
$$\lambda = \frac{2 \pi c}{\lambda^4}$$
 $\frac{1}{e^{hc/\lambda k T}}$ [photons/sec -cm² - μ m]

where* $c = 2.997925 \times 10^{10}$ cm/sec

 $h = 6.6256 \times 10^{-34}$ Joule - sec

 $k = 1.38054 \times 10^{-23}$ Joule / deg k

tf, tc, T

The three temperature scales, t_f , t_c , and T give blackbody temperature in degrees Fahrenheit, Centigrade, and Kelvin, respectively.

$$\lambda_1$$
 λ_2

The wavelength scales, λ_1 and $~\lambda_2$, give wavelength in the intervals

$$.3 \stackrel{<}{=} \lambda_1 \stackrel{<}{=} 30 \ \mu \ m$$
$$_{30} \stackrel{<}{=} \lambda_2 \stackrel{<}{=} 3000 \ \mu \ m$$

on the ENERGY side of the rule, and

$$.35 \le \lambda_1 \le 40 \ \mu \text{ m}$$

 $40 < \lambda_2 \le 4000 \ \mu \text{ m}$

on the PHOTONS side.

^{*} NBS Misc. Publ. 253, Revised May, 1969

$$v_1$$
, v_2

The wavenumber scales give wavenumbers in the intervals

$$320 \le v_1 \le 40000 \text{ cm}^{-1}$$

 $3.2 \le v_2 \le 400 \text{ cm}^{-1}$

on the ENERGY side, and

$$250 \le v_1 \le 30000 \text{ cm}^{-1}$$

$$2.5 \le v_2 \le 300 \text{ cm}^{-1}$$

on the PHOTONS side.

$$H_{O}^{-\infty}$$
, $Q_{O}^{-\infty}$

The H_0 - ∞ scale gives the value of

$$H_0 - \infty = \int_0^\infty H_{\lambda} d\lambda = \frac{2\pi^5 k^4}{15 k^3 c^2} T^4$$
 [W/cm²]

the total power radiated by unit area of a blackbody at temperature T.

The analogous photons scale, Q_0 - ∞ , gives

$$Q_{0-\infty} = \int_{0}^{\infty} Q_{\lambda} d\lambda = \frac{4 \pi k^{3}}{h^{3} c^{2}} (1.202057) T^{3}$$
 [photons / sec - cm²]

the total number of photons emitted by unit area of a blackbody at temperature T.

$$\frac{\mathrm{H}_{\lambda m}, \ \mathrm{Q}_{\lambda m}}{}$$

The H $_{\lambda}$ m scale gives the maximum value of the function H $_{\lambda}$ at a given value of T,

$$H_{\lambda m} = \frac{2 \pi k^5}{h^4 c^3}$$
 (21. 201436) T⁵ [W/cm² - μ m]

with

$$Q_{\lambda m} = \frac{2 \pi k^{4}}{h^{4} c^{3}} (4.77984) \quad T^{4}$$
 [photons / sec-cm² - \mu m]

the analogous maximum of the function $Q \lambda$.

H
$$_{\lambda\,1}$$
 / H $_{\lambda\,m}$, H $_{\lambda\,m}$ / H $_{\lambda\,m}$ Q $_{\lambda\,1}$ / Q $_{\lambda\,m}$, Q $_{\lambda\,2}$ / Q $_{\lambda\,m}$

These scales give the value of the indicated ratios for wavelengths read on either the λ_1 or λ_2 scales. They are

$$\frac{H_{O-\lambda_1}}{H_{O-\infty}}, \frac{Q_{O-\lambda_1}}{Q_{O-\infty}}, \frac{H_{\lambda_2-\infty}}{H_{O-\infty}}, \frac{Q_{\lambda_2-\infty}}{Q_{O-\infty}}$$

These scales give the fraction of blackbody power (or photon rate) emittance falling in the indicated wavelength interval. For wavelengths read from the λ_1 scale, the ratios are

$$\frac{H_0 - \lambda_1}{H_0^{-\infty}} = \sqrt{\frac{\frac{H_\lambda d \lambda}{H_\lambda d \lambda}}{\frac{H_\lambda d \lambda}{H_\lambda d \lambda}}} = \frac{15}{\pi^4} \sum_{n=1}^{\infty} \frac{e^{-nu}}{n^4} (n^3 u^3 + 3n^2 u^2 + 6 nu + 6 nu)$$

$$\frac{Q_0 - \lambda_1}{Q_0 - \infty} = \int_0^{\lambda_1} \frac{Q_{\lambda} d \lambda}{Q_{\lambda} d \lambda} = \frac{1}{2.404117} \sum_{n=1}^{\infty} \frac{e^{-nu}}{n^3} \qquad (n^2 u^2 + 2nu + 2)$$
(dimensionless)

where $u \equiv \frac{hc}{\lambda k T}$.

For convenience, the other integrated quantities are taken from λ_2 to ∞ :

$$\frac{H_{\lambda 2} - \infty}{H_{0 - \infty}} = \int_{0}^{\infty} \frac{H_{\lambda} d\lambda}{H_{\lambda} d\lambda} = 1 - \int_{0}^{\infty} \frac{H_{\lambda} d\lambda}{H_{\lambda} d\lambda}$$

$$\frac{Q_{\lambda 2} - \infty}{Q_{0 - \infty}} \int_{0}^{\infty} \frac{Q_{\lambda} d_{\lambda}}{\int_{0}^{\infty} Q_{\lambda} d_{\lambda}} = 1 - \int_{0}^{\infty} \frac{Q_{\lambda} d_{\lambda}}{\int_{0}^{\infty} Q_{\lambda} d_{\lambda}}$$

(dimensionles

$$V_n/\sqrt{R \Delta f}$$

This scale gives RMS Johnson noise potential per root ohm-hertz,

$$\frac{V_n}{\sqrt{R \Delta f}} = \sqrt{4k T} \qquad V/\sqrt{hz - \Omega}$$

$$^{\mathrm{E}}$$
 $_{\lambda}$ $_{\mathrm{m}}$

This scale gives the energy of a photon having wavelength $~\lambda$ m (at the maximum of H $~\lambda$) emitted at temperature T.

$$E_{\lambda m} = (4.965114) kT$$
 ev

The Stock Scales

Quantities which are functions of T alone, $H_{o-\infty}$, $Q_{o-\infty}$, λ_m , $H_{\lambda\,m}$, $Q_{\lambda\,m}$, $V_n/\sqrt{R\Delta f}$, $E_{\lambda\,m}$, can be read directly from the appropriate stock scales, when the hairline is set to the desired temperature.

EXAMPLE: Set the hairline to 1000° K on the T scale. Read directly beneath it

$$H_{O^{-\infty}} = 5.7 \text{ w/cm}^2$$
 $H_{\lambda m} = 1.3 \text{ w/cm}^2 - \mu \text{ m}$
 $V_0 / \sqrt{R \Delta f} = 2.34 \times 10^{-10} \text{ V/} \sqrt{\text{hz} - \Omega}$
 $\lambda_m = 2.9 \mu \text{ m} \text{ on the } \lambda_1 \text{ scale}$

from the ENERGY side of the stock, and the photon quantities

$$Q_{0-\infty}$$
 = 1.52 x 10²⁰ photons/sec - cm²
 $Q_{\lambda m}$ = 2.1 x 10¹⁹ photons/sec-cm² - μm
 $E_{\lambda m}$ = .427 ev
 λ_m = 3.67 μ m on the λ_1 scale

from the PHOTONS side of the stock.

^{**} Powers of ten are denoted in Feynman notation on this rule; e.g., $4 ext{ E} - 8$ is equal to $4 ext{ x } 10^{-8}$.

The Slide Scales

Quantities which are functions of both wavelength and temperature, $H_{\lambda l}/H_{\lambda m}$,

$$H_{\lambda 2} / H_{\lambda m}$$
, $Q_{\lambda 1} / Q_{\lambda m}$, $Q_{\lambda 2} / Q_{\lambda m}$, $H_{o-\lambda_1} / H_{o-\infty}$, $H_{\lambda_2 - \infty} / H_{o-\infty}$.

 $Q_{O^-\lambda_1}/Q_{O^{-\infty}}$ $Q_{\lambda_2-\infty}/Q_{O^{-\infty}}$ can be read from the appropriate slide scale when the central TEMPERATURE arrow on the slide is placed below the desired temperature, and the hairline is placed over the desired wavelength on the λ_1 or λ_2 scale.

EXAMPLE: Move the slide until the TEMPERATURE arrow is directly below 1000° K on the T scale. Set the hairline over 2 μ m on the λ_1 (ENERGY side) scale, and read beneath it

$$H_{\lambda l} / H_{\lambda m} = .68$$

 $H_{0-\lambda l} / H_{0-\infty} = 6.7 \times 10^{-2}$

for a blackbody at the given wavelength and temperature.

Turn the rule over to the PHOTONS side, reset the hairline to 2 $\mu\,m$ on the λ_1 scale, and read beneath it

$$Q_{\lambda 1} / Q_{\lambda m} = .42$$

 $Q_{o-\lambda 1} / Q_{o-\infty} = 2.1 \times 10^{-2}$.

Computing Absolute Bandpass Quantities

It is possible to compute various absolute quantities for a given wavelength interval by means of the relations

$$H_{\lambda 1} = \left(\frac{H_{\lambda 1}}{H_{\lambda m}}\right) \cdot H_{\lambda} \qquad H_{\lambda 2} = \left(\frac{H_{\lambda 2}}{H_{\lambda m}}\right) \cdot H_{\lambda m}$$

$$Q_{\lambda 1} = \left(\frac{Q_{\lambda 1}}{Q_{\lambda m}}\right) \cdot Q_{\lambda m} \qquad Q_{\lambda 2} = \left(\frac{Q_{\lambda 2}}{Q_{\lambda m}}\right) \cdot Q_{\lambda m}$$

and

$$\int_{A_{a}}^{A_{b}} H_{\lambda} d\lambda = \left(\frac{H_{o-\lambda b}}{H_{o-\infty}} - \frac{H_{o-\lambda a}}{H_{o-\infty}}\right). H_{o-\infty}$$

$$\int_{Q_{\lambda}}^{Q_{\lambda}} d_{\lambda} = \left(\frac{Q_{0-\lambda}b}{Q_{0-\infty}} - \frac{Q_{0-\lambda}a}{Q_{0-\infty}}\right) \cdot Q_{0-\infty}$$

for long wavelength intervals. The differential forms

$$H_{\lambda} \stackrel{\Delta \lambda}{=} A$$

may be used for small wavelength intervals. The four multiplier scales, $M(H_{\lambda m})$,

 $\not\!\!M$ ($H_{0^{-\infty}}$), $\,$ M (Q $_{\lambda\,m}$, M (Q $_{0^{-\infty}}$) have been included to expedite the required multiplications.

EXAMPLE: Compute the value of H $_{\lambda}$ associated with temperature T = 1500 o C and wavelength $_{\lambda}$ = 8.5 $_{\mu}$ m.

Move the slide until the TEMPERATURE arrow is directly beneath 1500 ^{o}C on the t_{c} scale. Then set the hairline over 8.5 μ m on the λ_{1} scale and read the value of H $_{\lambda}/$ H $_{\lambda}{}_{m}$, 2.4 x 10-2, directly beneath it on the H $^{\lambda}{}_{l}/$ H $_{\lambda}{}_{m}$ scale. Transfer this value to the M (H $_{\lambda}{}_{m}$) multiplier scale by resetting the hairline, and read

$$H_{\lambda} = .54 \text{ W/cm}^2 - \mu \text{ m}$$

beneath it on the H $_{\lambda}$ m scale.

EXAMPLE: Compute $H_{0-\lambda}$ for a temperature of 350 F and wavelength of 20 μ m.

First compute the value of

$$\frac{H_{0-\lambda}}{H_{0-\infty}} = .89$$

as before. Transfer this value to the M ($H_{O^{-\infty}}$) scale by resetting the hairline; read beneath it

$$H_{0-\lambda_1} = .21 \text{ W/cm}^2$$

on the $H_{o^{-\infty}}$ scale.

Extending the range of a scale

The stock scales may be used with higher or lower values of temperature than those represented on the rule. Simply multiply the desired (absolute) temperature by 10 raised to a convenient power, so that the new temperature appears on the T scale. Solve the problem using this new value of T, then multiply the result by the appropriate factor as listed in Table 1.

Table 1

If T is multiplied by	multiply the value of	by a factor of
10 ⁻ⁿ	HO-∞	10^{4n}
10 ⁻ⁿ	$Q_{O^{-\infty}}$	$10^3\mathrm{n}$
10 ⁻ⁿ	Η _{λm}	= 10 ⁵ⁿ
10 ⁻ⁿ	$Q_{\lambda m}$	10 ⁴ n
10 ⁻ⁿ	Vn/√R △	\bar{f} $10^{n/2}$
10 ⁻ⁿ	Ε _{λm}	10 ⁿ

NOTE: Without recourse to Table 1, it is possible to deduce the required factor by inspection of the scale itself. For example, if T is reduced by a factor of ten in going from 1000° K to 100° K, say the value of $Q_{o-\infty}$ evidently decreases by a factor of 10° K 1.52×10^{20} to 1.52×10^{17} Thus, an additional ten-fold temperature reduction to 10° K would give $Q_{o-\infty} = 1.52 \times 10^{14}$ photons/sec. cm².

A similar extension procedure can be used with each of the stock scales.

EXAMPLE: Find $Q_{Q^{-\infty}}$ for a blackbody at temperature $T=20,000^{0}K$. Using the $Q_{Q^{-\infty}}$ scale, solve the problem for $T=2,000^{0}K$ (20,000 $K \times 10^{-1}$). The result is 1.22 x 10 photons/sec. cm². Now multiply this number by a factor of 10^{3} = 10^{3} to give

$$Q_{0-\infty} = 1.22 \times 10^{24}$$
 photons/sec. cm²

The slide scales can also be used over an extended range of temperature and wavelength. Select new, convenient values of λ and T such that the product λ T is the same as for the original problem. The result obtained in this way will be correct without modification.

EXAMPLE: Find $H_{\lambda}/H_{\lambda m}$ for T-15000° k and $\lambda = .25 \ \mu m$.

Here, the product λT will be unchanged if the problem is solved for $T=1500^{\circ} k$ and $\lambda=2.5~\mu$ m. Using the $H_{\lambda\,1}$ / $H_{\lambda m}$ and T scales, the result is

$$\frac{H \lambda}{H \lambda}_{m} = .86$$

for the desired temperature and wavelength.

NOTE: If absolute quantities are subsequently to be derived by means of the slide multiplier scales, it is necessary to modify the results obtained according to Table 1.

Sample Problems (cf. appendix for more detailed solutions)

How much radiant power is emitted by a 1.0 square cm. piece of firebrick at 1000 °C? The total emissivity of firebrick at this temperature is .75.

Solution:
$$P = H_{0-\infty}$$

= (.75) (15) W/cm²
= 11 W/cm²

using the t_c , $H_{o^{-\infty}}$ and $M(H_{o^{-\infty}})$ scales.

What is the RMS Johnson noise potential developed across a 10,000 Ω resistor at a temperature of 175 $^{0}\mathrm{F}$ in a 1-hz bandwidth?

Solution:
$$Vn = \left(\frac{Vn}{\sqrt{R \Delta f}}\right) \cdot \sqrt{R \Delta f} \quad \text{for } 175^{\circ} \text{F}$$

$$Vn = 1.39 \times 10^{-10} \frac{V}{\sqrt{\text{hz} - \Omega}} \cdot \sqrt{10,000 \Omega \cdot 1} \text{ hz}$$

$$= 1.39 \times 10^{-8} \text{ V}$$

using the t_f and Vn/\sqrt{R} $\triangle f$ scales.

How much radiant power is emitted by 1.0 sq. cm of a tungsten rod at temperature 2800° K in the wavelength interval $.7 \le \lambda \le .75 \ \mu$ m? The emissivity of tungsten in this interval is .42.

Solution:
$$\triangle H = \in \int_{A_{\lambda}}^{A_{\lambda}} H_{\lambda} d\lambda \text{ for } T = 2800^{\circ} K$$

$$= (.42) \int_{A_{\lambda}}^{A_{\lambda}} H_{\lambda} d\lambda$$

$$= .42 \int_{A_{\lambda}}^{A_{\lambda}} \left\{ \int_{A_{\lambda}}^{A_{\lambda}} H_{\lambda} d\lambda - \int_{A_{\lambda}}^{A_{\lambda}} H_{\lambda} d\lambda \right\}$$

$$= .42 \left(\frac{H_{0-.75 \ \mu m}}{H_{0-...}} - \frac{H_{0-.75 \ \mu m}}{H_{0-...}} \right) \cdot H_{0-...}$$

$$= .42 (.083 - .060) \cdot H_{0-...}$$

$$= .42 (.023) H_{0-...}$$

$$= (.42) 8.0 W$$

$$= 3.4 W$$

using the T, λ_1 , $H_{_{O}-\lambda_1}$ / $H_{_{O}-\infty}$, M(H_{_{O}-\infty}) , $H_{_{O}-\infty}$, C and D scales.

What is the photon count from a 1.0 cm 2 blackbody at 3000° C in the interval 15,000 \leq v \leq 25,000 cm $^{-1}$?

Solution:
$$\Delta Q = \int_{\mathbf{V}=25.000}^{\mathbf{V}=3.000} \mathbf{Q}_{\lambda} d\lambda$$
 at 3000° C

$$= \left(\frac{Q_{o-15000 \text{ cm}}^{-1}}{Q_{o-\infty}} - \frac{Q_{o-25000 \text{ cm}}^{-1}}{Q_{o-\infty}}\right) \cdot Q_{o-\infty}$$

$$= (.033 - .001) \cdot Q_{o-\infty}$$

$$= .032 Q_{o-\infty}$$

$$= 1.7 \times 10^{20} \text{ photons/sec}$$

using the $t_c^{}$, $v_1^{}$, $^Q_{o^{-\lambda}_1}^{}$ / $^Q_{o^{-\infty}}^{}$, $M(^Q_{o^{-\infty}}^{})$ and $^Q_{o^{-\infty}}^{}$ scales.

How much total radiant power is emitted by a 1.0 square cm. blackbody at temperature $T = 45^{\circ}K$?

Solution:
$$H = H_{0-\infty}$$

= .23 x 10⁻⁴ W
= 2.3 x 10⁻⁵ W

using the T and $H_{0-\infty}$ scales with Table 1.

Find the total radiant power emitted by a $6000^{0}K$ blackbody in a 100 Å $\,$ band width around .35 μ m

Solution:
$$\Delta H = H_{\lambda} \Delta \lambda$$

$$= \left(\frac{H_{\lambda}}{H_{\lambda m}}\right) \cdot H_{\lambda m} \Delta \lambda$$

$$= .75 H_{\lambda m} \Delta \lambda$$

$$= 7.5 \times 10^{3} \text{ W/cm}^{2} - \mu \text{ m} \times 100 \times 10^{-4} \mu \text{ m}$$

$$= 75 \text{ W/cm}^{2}$$

using the T, λ_l , H $_{\lambda\,l}$ / H $_{\lambda\,m}$, M (H $_{\lambda\,m}$) and H $_{\lambda\,m}$ — scales.

How much radiant power is received from a 4.0 cm² blackbody source at 2700°K if the blackbody is directly in front of the receiver, 100 cm away?

Solution:
$$H = \frac{S_b}{\pi d^2}$$
 $H_{0-\infty}$

where d = distance between viewer and source; S = radiating blackbody ar

$$H = \frac{4.0 \text{ cm}^2 \text{ x } 3.0 \text{ x } 10^2 \text{ W/cm}^2}{3.14 \text{ x } (100)^2 \text{ cm}^2}$$

$$H - 3.8 \times 10^{-2} \text{ W/cm}^2$$

receiver

using the T, $H_{0-\infty}$, C and D scales.

APPENDIX

Sample Problem 1: Set the hairline to 1000° C on the t_{c} scale, and read the value 15 W/cm² on the $H_{O^{-\infty}}$ scale. To multiply this number by the emissivity, .75, the M($H_{O^{-\omega}}$) multiplier scale may be used: move the slide until the TEMPERATURE arrow is on 1000° C. Then set the hairline over .75 on the M ($H_{O^{-\infty}}$) scale, and read the required result, 11 W/cm², on the $H_{O^{-\infty}}$ scale.

Sample Problem 2: Set the hairline to the temperature, $175^{\circ}F$ on the t_f scale. Read the value of Vn $/\sqrt{R} \Delta f$, 1.39 x 10^{-10} V/ $\sqrt{hz-\Omega}$, and multiply this by the value of

$$\sqrt{R \Delta f} = \sqrt{10,000 \Omega \cdot 1 \text{ hz}} = 100 \sqrt{\text{hz} - \Omega}$$

The result if $Vn = 1.39 \times 10^{-8}$ V. For more difficult numberical values, the square root may be found using the T and D scales: the D scale will read-out directly the square root of the number under the hairline on the T scale. Multiplication can then be carried out with the C and D scales.

Sample Problem 3: Set the TEMPERATURE arrow to 2800° K on the T scale, and move the hairline to .75 µm on the λ_1 scale. Read the value of $H_{0-\lambda 1}/H_{0-\infty}$, .083. Now, move the hairline to .7 µm and read the value of $H_{0-\lambda 1}/H_{0-\infty}$ for this wavelength .060. The difference of these two values, .083 - .060 = .023 must be multiplied by $H_{0-\infty}$; set the hairline over .023 on the M ($H_{0-\infty}$) scale and read the value 8.0 W from the $H_{0-\infty}$ scale. Now use the C and D scales to multiply this number by .42, the emissivity. The result is 3.4 W.

Sample Problem 4: Move the TEMPERATURE arrow to read $3000^{\circ} C$ on the t_c scale, and set the hairline over 15,000 cm⁻¹ on the V_1 scale. Read the value of $Q_{o-\lambda 1}/Q_{o-\infty}$, .033. Reset the hairline to 25,000cm⁻¹ and read the value of $Q_{o-\lambda 1}/Q_{o-\infty}$ for this frequency, .001. Compute the difference of these two values, .033-.001=.032 and set the hairline to this number on the M $(Q_{o-\infty})$ scale. Read the required result, 1.7 x 10^{20} photons/sec, from the $Q_{o-\infty}$ scale.

Sample Problem 5: Since the temperature of interest, 45° K, is below the range of the T scale, multiply it by 10' and set the hairline to the new temperature, 450° K, on the T scale. Read the value .23W on the $H_{0-\infty}$ scale. Since the value of T was multiplied by $10^{-n} = 10^{\circ}$, n = -1 here, and the value .23W must be multiplied by a factor of $10^{4n} = 10^{-4}$ to give the correct result for $T = 45^{\circ}$ K. It is

$$H_{0^{-\infty}} = .23 \times 10^{-4} \text{ W}$$

= 2.3 x 10⁻⁵ W.

Sample Problem 6: For this small wavelength interval, the differential form

$$\int_{A}^{b} H_{\lambda} d\lambda = H_{\lambda} (\lambda b - \lambda a) = H_{\lambda} \Delta \lambda$$

is used. Set the TEMPERATURE ARROW to 6000° K on the T scale. Set the hairline to .35 μm on the λ scale, and read the value of $H_{\lambda l}$ / $H_{\lambda m}$, .75 . Reset the hairline to this number on the M ($H_{\lambda m}$) scale, then read the value of H_{λ} = 7.5 x 10^3 W/cm²- μ from the H $_{\lambda m}$ scale. Multiply this number by $\Delta\lambda$ = 100 A = 100 x 10^{-4} μ m. The result is ΔH = 75 W/cm².

Sample Problem 7: Set the hairline to 2700° K on the T scale, and read beneath it the value of $H_{0-\infty}$, 3.0 x 10^{2} W/cm². Now use the C and D scales to multiply this number by

$$\frac{S_b}{IId^2} = \frac{4.0 \text{ cm}^2}{3.14 \text{ x (100)}^2 \text{ cm}^2}$$

The result is $H = 3.8 \times 10^{-2} \text{ W/cm}^2$ receiver.

References:

H. W. Makowski, "A Slide Rule for Radiation Calculations," Review of Scientific Instruments, 20, 876 (1949)

M. Pivovonsky and M. R. Nagel, <u>Tables of Blackbody Radiation Functions</u>, Macmillan Co., N. Y. (1961)

HOW TO ADJUST YOUR SLIDERULE

Each rule is accurately adjusted before it leaves the factory. However, handling during shipment, dropping the rule, or a series of jars may loosen the adjusting screws and throw the scales out of alignment. Follow these simple directions for slide rule adjustment.

ALIGNMENT OF RULE BODY

- 1. Position your slide rule so that the adjusting screws in the two end-plates are up and away from you.
- 2. Loosen the two end-plate screws to achieve slight flexibility in the rule
- 3. Position the slider (or center part of the rule so that its left index is aligned with the index on the fixed stator (at the bottom of the rule).
- 4. Keeping the slider aligned, position the movable stator (at the top of the rule) so that its index is aligned with the slider.
 - 5. With the thumb and forefinger, apply slight pressure to the left side of the rule, and tighten the screw. (Leave a small gap between the slider and stators to achieve smooth rule movement: approximately .003".)
 - 6. Apply slight pressure to the right side of the rule and tighten that adjusting screw again leaving a small gap.
- 7. Confirm alignment on the reverse side of the rule.

ALIGNMENT OF WINDOW ASSEMBLY

- 1. Loosen all screws on both sides of the window assembly to make the assembly flexible.
- 2. Working on one side of the rule, locate the unsprung cursor bar; e.g., the bar that does not have a tension spring. (Cursor bars are the opaque teflon components that ride on the edge of the rule.)

- 3. Using thumb and forefinger, apply upward pressure to the bottom of the unsprung bar so that it rests firmly against the rule's edge.
- 4. Also position the window so that the hairline is perpendicular to the index lines on the left side of the rule. Tighten the screw(s) in the unsprung bar. Leave the other Screw(s) loose.
- 5. Turn the rule over and repeat the preceding steps:
- a. Apply pressure against the cursor bar which has no spring. b. Make certain the hairline is perpendicular to the left index
- c. Tighten the screw(s) in the unsprung bar,
- 6. Continuing on the same side of the rule, tighten the screw(s) in the cursor bar, which is spring-loaded.
- 7. Reverse the rule and tighten the remaining screw(s) in the spring-loaded bar.
- 8. Move the window to the opposite end of the rule to confirm alignment with the righthand index.

REPLACEABLE ADJUSTING SCREWS

HOW TO KEEP YOUR SLIDE RULE IN CONDITION

Operation

Always hold your rule between thumb and forefinger at the ends of the rule. This will insure free, smooth movement of the slider. Holding your rule at the center tends to bind the slider and hinder its free movement.

Cleaning

Wash surface of the rule with a non-abrasive soap and water when cleaning the scales.

Lubrication

The metal edges of your slide rule will require lubrication fom time to time. To lubricate, put a little white petroleum jelly (Vaseline) on the edges and move the slider back and forth several times. Wipe off any excess lubricant. Do not use ordinary oil as it may eventually discolor rule surface.